

Joint Agency Command Post



2016 Freightliner/Frontline

Specifications

- Motor - Cummins 450 HP
- Front Axle WR - 14,600lbs
- Intermediate Axle WR - 20,000lbs
- Rear Axle WR - 20,000lbs
- Vehicle Height - 13' 6"

Clearances



WARNING

This vehicle is the maximum allowable height to travel on public roadways. Beware of any low clearance situations.

In addition to the height, the rollers for the retractable awnings extend beyond the side of the vehicle. They are very high and not visible in the mirrors.

Clearances - Awnings




Auxiliary Braking Device

CAUTION

**This unit is equipped with an
Exhaust Brake.**

**The Exhaust Brake will not be used in low
traction or slippery conditions.**

Transmission Fluid Check



- The Transmission Fluid level may be checked in the cab through the keypad selector.
- The engine must be running at idle and the unit must be on level ground.
- The engine must idle at least five minutes from a cold start.
- The transmission must heat to at least 140 degrees F.
- Push both the up and down arrows simultaneously on the keypad.

Transmission Fluid Check



- After simultaneously pushing both buttons, the symbol “OL” will display on the screen.
- OL will be followed by OK, -1 thru -7, or +1 thru +7. The – indicates under filled and the + indicates overfilled. The numeral indicates the number of quarts.
- Any other message indicates a problem and CMF should be notified.
- Always confirm the digital reading on the dipstick BEFORE adding fluid.
- ONLY use Trans-Synd Fluid.

Reverse Camera



- The video screen is located at ceiling level in the center of the unit.

- The camera is located on the AC unit.



Cab Features



Cab Features

Driver's
Window

Passenger's
Window

Mirror
Heat


Door Locks

Use of this switch will
lock/unlock the cab
ONLY – not the body



Cab Features

Parking Brake



Rear
Suspension
Dump

(This can be used
when the vehicle is off
to dump the rear air if
the stabilization
system fails)

Cab Features



REAR AIR SUSPENSION



INTERIOR
LIGHTS



PORCH
LIGHT



CO / SMOKE
ALARM



TIRE
CHAINS



CAUTION !

CHAINS MUST BE ENGAGED AND DISENGAGED WHILE THE VEHICLE IS MOVING.

- CHAINS MUST BE ENGAGED WHEN TRAVELING BETWEEN 2 MPH and 25 MPH.
- CHAINS MUST BE DISENGAGED WHEN TRAVELING BETWEEN 2 MPH and 35 MPH.
- VEHICLE MUST NOT EXCEED 35 MPH WITH THE CHAINS ENGAGED.

Cab Features

Inter-Axle
Lock



Exhaust Brake



Manual
Regeneration



Cab Features

Arrow Stick
Control

Warning Light
Controls

Siren Controls



Cab Features

- Top row are switches
 - Battery Parallel links chassis and coach batteries



- Bottom row are warning lights
 - **DO NOT** move vehicle if any are illuminated

Cab Features

- Steering Wheel Adjustment



Step on adjustment pedal for telescoping and tilt functions.
Releasing the pedal will lock the steering wheel in place.

Cab Features

- This unit is equipped with Automatic Traction Control
- Up turns the system “off” and allows wheels to spin
- Down is the normal position and allows the ATC to brake and transfer power as needed




Cab Features

- On-Spot Tire Chains
 - Not installed yet



Cab Features

- Mirrors
 - Both Mirrors are heated
 - Large flat mirror is remotely adjustable
 - Convex mirror is manual



Move the mirror

Select the mirror



Control located on Driver's Door

Regeneration

- 1) All diesel exhaust systems must be fitted with a DPF and a regeneration system.
- 2) DPF is Diesel Particulate Filter which captures soot and ash from the engine exhaust.
- 3) Regeneration is the process of burning off the soot and ash.
- 4) There are two types of regeneration:
 1. **Passive which requires no driver involvement.**
 2. **Active which requires driver involvement.**
- 5) Warning lights in the dash cluster will advise the driver of what action is needed.

Regeneration

- Active Parked Regeneration

- 1) When the DPF lamp is solid a parked regeneration may be needed.
- 2) When the DPF lamp is flashing a parked regeneration is REQUIRED AS SOON AS POSSIBLE
- 3) During a regeneration exhaust temperature can reach 1300 degrees. Select an appropriate location.
- 4) Park unit, place the transmission in neutral, chock the wheel, and toggle the regeneration switch. Engine rpm should increase to approximately 1100rpm.
- 5) Keep exhaust 5 feet away from all objects and pedestrians.
- 6) The driver must remain with the vehicle during regeneration.

Regeneration

- Active Parked Regeneration

- 7) During the regeneration process the high exhaust temperature lamp will illuminate.
- 8) DO NOT complete regeneration in the Station or while connected to a Plymovent.
- 9) When the ECM determines the DPF has been regenerated engine rpm will decrease to normal rpm signaling the regeneration is over.
- 10) Remember exhaust components are still very hot.
- 11) If the regeneration process needs to be interrupted or stopped, depress the brake pedal.

Regeneration




- Active Parked Regeneration



The regeneration switch is located in the center of the dash below the Axle Lock switch.

Regeneration


- DPF/DEF Warning Lights

IMPORTANT	
<p>DPF Regen Needed</p> 	<ul style="list-style-type: none">• Diesel Particulate Filter (DPF) regeneration is needed.• If flashing, regenerate as soon as possible. Engine derate possible.
<p>Hot Exhaust</p> 	<ul style="list-style-type: none">• Hot exhaust can cause fire.• Keep flammables and people away from exhaust.
<p>DEF Refill Needed</p> 	<ul style="list-style-type: none">• Diesel Exhaust Fluid (DEF) level is low. Engine derate likely.• Refill tank with certified DEF.
<p>See operator's manual or glove compartment card for complete instructions.</p>	

Regeneration

- Passive Regeneration
 - Passive Regeneration will only occur during highway driving
 - It is unlikely this unit will drive enough highway miles for Passive Regeneration to complete its cycle

Diesel Exhaust Fluid




**Diesel FUEL
Tank**

**Diesel EXHAUST
FLUID Tank**

Diesel Exhaust Fluid



DEF Tank located rear of Fuel tank on the driver's side of the unit.




DEF Tank gauge located below fuel gauge on dash.

Batteries

- The vehicle has 2 banks of batteries
 - Chassis Batteries are located under the driver's seat
 - Coach batteries are located in the first driver side compartment
 - The systems are separate
 - Can be linked by pressing either “Battery Parallel” switch



Coach Batteries



Coach Batteries



Leveling & Stabilization System

- 4 Electric Stabilizer Jacks are under the vehicle
- Control panel located beside entry door
- System is automatic with manual overrides
- Intended to stabilize vehicle and overcome MINOR slope differences
- Vehicle should be parked on solid ground that is as flat and level as possible
- When necessary, cribbing or ground pads may be needed

Leveling & Stabilization System

- Press “System Power” button
- Press “Auto” button
 - Rear air suspension will automatically dump
 - Stabilizers will deploy automatically
- This may take a few minutes
- Stabilization complete when footprint indicator light turns green
- This **MUST** be done before any slides or accessories are deployed

Stabilization System



- Initial Power Up
 - System Power lit
 - All Up lit – indicates everything is stowed



- Vehicle Stabilized
 - System Power lit
 - Auto lit
 - Green Foot lit

Stabilization System



12 Volt DC Control Panel

- Located above door in the coach
 - All 12 volt functions
 - Passenger side awning
 - Slide Room Control Panel
 - Generator start



12 Volt DC Control Panel

DC CONTROL

Ps SCENE LIGHTS



Ds SCENE LIGHTS



REAR SCENE LIGHTS



PORCH LIGHT



INTERIOR LIGHTS



MAST LIGHT



MAST STROBE LIGHT



COMPARTMENT LTS



GEN REMOTE



BATTERY PARALLEL



SYSTEM ☐ VEHICLE

RACK SERVICE LIGHTS



SLIDEOUT LIGHT



FUEL LEVEL



PUSH TO READ
FUEL LEVEL



COMM 1



COMM 2



COMM 3



Generator

- Unit is equipped with a 30kW diesel powered generator
- Shares fuel tank with chassis
- Can power ALL functions of unit simultaneously
- Located in second compartment on driver's side
- Compartment is completely enclosed allowing the generator to be run while driving
- Started on the 12 Volt Control Panel in the back

Generator - Starting

- To start generator go to DC Control Panel
- Press Generator Remote switch
- Generator will start after glow plugs have cycled



120 Volt Power Distribution System

- Located opposite door in the coach
- Controls all 120 volt AC functions



120 Volt Power Distribution System

CAUTION

The following steps MUST be completed exactly as shown. Failure to follow the proper order can cause significant damage to the electrical system

120 Volt Power Distribution System

Startup Step 1

- **Start the generator** – green light illuminated
- Check the right side of the 120 Volt panel
- The panel should appear as shown
- Power Select OFF
- Main Breaker OFF



120 Volt Power Distribution System

Startup Step 2

- Turn the **POWER SELECT** switch to **GEN**

- The panel should appear as shown
- Power Select GEN
- Main Breaker OFF

Before proceeding confirm that the L1 and L2 gauges both show 120 volts and the center gauge shows 60 hertz



120 Volt Power Distribution System

Startup Step 3

With the L1 and L2 gauges at 120 volts and the center gauge at 60 hertz you can proceed


- Turn the MAIN breaker on (UP)
- The panel should appear as shown
- Power Select GEN
- Main Breaker ON
- L1 & L2 120 volts
- Center 60 hertz



120 Volt Power Distribution System


Startup Step 4

- Individual breakers can now be turned on for desired components




HVAC System

- Air conditioning unit is on rear of vehicle
- HVAC Breaker must be on
- Thermostat next to breaker panel



HVAC System

- Electric heaters located in front and rear rooms
- Corresponding Wall Heater Breaker must be on
- Thermostat located on heater



Hydraulic Room Extensions

- There are 4 hydraulic room extensions
 - 2 in the front conference room
 - 2 in the rear workstation area
- Powered by 12 volt hydraulic pump
- Pump and reservoir located in the left rear compartment
- Rooms extend roughly 3 feet

**Check for obstructions
BEFORE extending the rooms.
Position a spotter during
extension if in doubt!**



Hydraulic Room Extensions

- The reservoir FULL line is for when ALL 4 rooms are deployed
 - Plans to mark reservoir with retracted fluid level
- Manual pump also located here



Hydraulic Room Extensions

- Controls for room extensions located on 12 volt DC control panel above entry door
 - Turn system ON
 - Select extension
 - Press extend to deploy or retract to stow



**Check for obstructions on the exterior BEFORE extending the rooms. Position a spotter during extension if in doubt!
Check for interior obstructions BEFORE retracting.**

Awnings

- Electric awning on both sides above extensions
 - Require 120 volt power
 - Can be stopped at desired length
 - Have wind sensors to automatically retract



Awnings

- Passenger side awning controls located on 12 volt DC control panel above entry door
 - Turn on awning breaker on 120 volt panel
 - Turn on awning control
 - Ensure no obstructions
 - Extend awning to desired length
 - Adjust motion (wind) sensitivity as desired



**Check for obstructions BEFORE extending the awnings.
Position a spotter during extension if in doubt!**

Pneumatic Mast




DANGER

**ALWAYS check for overhead
obstructions before deploying
mast**

**NEVER operate mast within 10
feet of power lines**

Pneumatic Mast

- 40' Pneumatic Mast located on driver's side rear of unit
 - Controls and 120v air compressor located in driver's rear compartment
 - Level the vehicle before deploying





Pneumatic Mast



Pneumatic Mast

- Handheld spotlight provided for checking for overhead obstructions



Pneumatic Mast



In the event of a failure of the handheld controller, there is a dump valve to allow manual retraction of the mast.

Startup & Shutdown Steps

- Separate documents have been created to provide step-by-step instructions for basic setup upon arrival at a scene and demobilizing from a scene.

Questions regarding the vehicle should be directed to Special Operations.